

Ademco/First Alert Alpha Zone Descriptors

At end of *56 Zone programming or if entering *82 keypad shows

Program Alpha? 0 = No 1 = Yes 0	Press 1 for Yes
Custom Words? 0 = No 1 = Yes 0	Press 0 for No at "Custom Words?" (for now anyway)
★ ZN 01 ZONE 01	Press * then enter Zone number (01 to 99)
★ ZN 01	Display is waiting for 1st word, press # + 3-digit number from word list below
★ ZN 01 FRONT	1st word appears, 6 saves and moves to next word, 8 ends or select another word with # + 3-digit number from word list below
★ ZN 01 FRONT _	Display is waiting for 2nd word, press # + 3-digit number from word list below
★ ZN 01 FRONT ENTRY	2nd word appears, 6 saves and moves to next word, 8 ends or select another word with # + 3-digit number from word list below
★ ZN 01 FRONT ENTRY _	Display is waiting for 3rd word, press # + 3-digit number from word list below
★ ZN 01 FRONT ENTRY DOOR	3rd word appears, 6 or 8 saves new Zone descriptions or select another word or press *00 to exit to "Program Alpha?"

Custom Words

At end of zone programming or if entering *82 keypad shows

Program Alpha? 0 = No 1 = Yes 0	Press 1 for Yes
Custom Words? 0 = No 1 = Yes 0	Press 1 for Yes
Custom ?	Enter Custom Word to program then * (if Vista-10/Via-30 use 1 to 5) (if Vista-15/Vista-20 use 01 to 10)
Custom 1 _	Display is waiting for 1st letter, press # + 2-digit number from Custom word list
Custom 1 <u>M</u>	1st letter appears, 4 moves cursor left, 6 moves cursor right, 8 saves or select another letter with # + 2-digit number from custom word list
Custom 1 M_	Display is waiting for 2nd letter, press # + 2-digit number from Custom word list
Custom 1 MA	2nd letter appears, 4 moves cursor left, 6 moves cursor right, 8 saves or select another letter with # + 2-digit number from custom word list
Custom 1 MARK_	Continue until word is created (up to 10 characters) then 8 to save
Custom Words? 0 = No 1 = Yes 0	Press 0 to return to "Program Alpha?" prompt

Use Custom Words like regular words from Standard Word List

Vista-10/Via-30 locations 250 to 254
Vista-15/Vista-20 locations 245 to 254

Ademco/First Alert Alpha Zone Descriptors

Standard Word List - (Bold words are spoken if 4285 phone module is used)

000 (Word Space)	057 DOOR	109 LIBRARY	162 ROOM	219 WING
001 AIR	059 DOWN	110 LIGHT	163 ROOF	220 WIRELESS
002 ALARM	060 DOWNSTAIRS	111 LINE	164 SAFE	222 XMITTER
004 ALLEY	061 DRAWER	113 LIVING	165 SCREEN	223 YARD
005 AMBUSH	062 DRIVEWAY	114 LOADING	166 SENSOR	224 ZONE (No.)
006 AREA	064 DUCT	115 LOCK	167 SERVICE	225 ZONE
007 APARTMENT	065 EAST	116 LOOP	168 SHED	226 0
009 ATTIC	066 ELECTRIC	117 LOW	169 SHOCK	227 1
010 AUDIO	067 EMERGENCY	118 LOWER	170 SHOP	228 1ST
012 BABY	068 ENTRY	119 MACHINE	171 SHORT	229 2
013 BACK	069 EQUIPMENT	121 MAIDS	173 SIDE	230 2ND
014 BAR	071 EXIT	122 MAIN	174 SKYLIGHT	231 3
016 BASEMENT	072 EXTERIOR	123 MASTER	175 SLIDING	232 3RD
017 BATHROOM	073 FACTORY	125 MEDICAL	176 SMOKE	233 4
018 BED	75 FAMILY	126 MEDICINE	178 SONS	234 4TH
019 BEDROOM	076 FATHERS	128 MONEY	179 SOUTH	235 5
020 BELL	077 FENCE	129 MONITOR	180 SPRINKLER	236 5TH
021 BLOWER	079 FIRE	130 MOTHERS	182 STATION	237 6
022 BOILER	080 FLOOR	131 MOTION	184 STORE	238 6TH
023 BOTTOM	081 FLOW	132 MOTOR	185 STORAGE	239 7
025 BREAK	082 FOIL	134 NORTH	186 STORY	240 7TH
026 BUILDING	083 FOYER	135 NURSERY	190 SUPERVISED	241 8
028 CABINET	084 FREEZER	136 OFFICE	191 SUPERVISION	242 8TH
029 CALL	085 FRONT	138 OPEN	192 SWIMMING	243 9
030 CAMERA	089 GARAGE	139 OPENING	193 SWITCH	244 9TH
031 CAR	090 GAS	140 OUTSIDE	194 TAMPER	
033 CASH	091 GATE	142 OVERHEAD	196 TELCO	(Vista-10/Via-30)
034 CCTV	092 GLASS	143 PAINTING	197 TELEPHONE	250 Custom Word #1
035 CEILING	093 GUEST	144 PANIC	199 TEMPERATURE	251 Custom Word #2
036 CELLAR	094 GUN	145 PASSIVE	200 THERMOSTAT	252 Custom Word #3
037 CENTRAL	095 HALL	146 PATIO	201 TOOL	253 Custom Word #4
038 CIRCUIT	096 HEAT	147 PERIMETER	202 TRANSMITTER	254 Custom Word #5
040 CLOSED	098 HOLDUP	148 PHONE	205 UP	
046 COMPUTER	099 HOUSE	150 POINT	206 UPPER	(Vista-15 and 20)
047 CONTACT	100 INFRARED	151 POLICE	207 UPSTAIRS	245 Custom Word #1
048 DAUGHTERS	101 INSIDE	152 POOL	208 UTILITY	246 Custom Word #2
049 DELAYED	102 INTERIOR	153 POWER	209 Valve	247 Custom Word #3
050 DEN	103 INTRUSION	155 Radio	210 VAULT	248 Custom Word #4
051 DESK	104 JEWELRY	156 REAR	212 VOLTAGE	249 Custom Word #5
052 DETECTOR	105 KITCHEN	157 RECREATION	213 WALL	250 Custom Word #6
053 DINING	106 LAUNDRY	159 REFRIGERATION	214 WAREHOUSE	251 Custom Word #7
054 DISCRIMINATOR	107 LEFT	160 RF	216 WEST	252 Custom Word #8
055 DISPLAY	108 LEVEL	161 RIGHT	217 WINDOW	253 Custom Word #9
				254 Custom Word #10

Ademco/First Alert Alpha Zone Descriptors

Custom Word List - (Cannot be spoken by 4285 phone module)

32 (space)	42 *	52 4	62 >	72 H	82 R
33 !	43 +	53 5	63 ?	73 I	83 S
34 "	44 ,	54 6	64 @	74 J	84 T
35 #	45 -	55 7	65 A	75 K	85 U
36 \$	46 .	56 8	66 B	76 L	86 V
37 %	47 /	57 9	67 C	77 M	87 W
38 &	48 0	58 :	68 D	78 N	88
39 '	49 1	59 ;	69 E	79 O	89 Y
40 (50 2	60 <	70 F	80 P	90 Z
41)	51 3	61 =	71 G	81 Q	

Property of Monitronics Inc