

Ademco 5140XM/First Alert FA1500C Program Sheet

Enter Program 1. 5140 + 8 + 0 + 0 (Display should show 00)
 or Power down then back up and press * and # within 1 minute
 (If exiting programming you can re-enter within 1 minute by pressing * and #)

Move to Location * + Location

View Location # + Location (Display will read off one digit at a time)

Exit Program 1. *98 OR 2. *99 if needing to re-enter programming later by Code + 8 + 00

***00 Installer Code** 5 1 4 0

| | | |
|--|--|--|
| <p>*02 Zone Types for Zones 1 to 8</p> <p><u> ? </u> <u> ? </u> Zone 1 <u> ? </u> <u> ? </u> Zone 2 <u> ? </u> <u> ? </u> Zone 3 <u> ? </u> <u> ? </u> Zone 4 <u> ? </u> <u> ? </u> Zone 5 <u> ? </u> <u> ? </u> Zone 6 <u> ? </u> <u> ? </u> Zone 7 <u> ? </u> <u> ? </u> Zone 8</p> <p>*04 Zone Type for Zone 17 to 24</p> <p><u> ? </u> <u> ? </u> Zone 17 <u> ? </u> <u> ? </u> Zone 18 <u> ? </u> <u> ? </u> Zone 19 <u> ? </u> <u> ? </u> Zone 20 <u> ? </u> <u> ? </u> Zone 21 <u> ? </u> <u> ? </u> Zone 22 <u> ? </u> <u> ? </u> Zone 23 <u> ? </u> <u> ? </u> Zone 24</p> <p>*09 Entry Delay <u> 0 </u> <u> 2 </u></p> <p>*10 Exit Delay 1 <u> 0 </u> <u> 4 </u></p> <p>*11 Entry Delay 2 <u> 0 </u> <u> 3 </u></p> <p>*12 Exit Delay 2 <u> 0 </u> <u> 4 </u></p> <p>*13 Bell 1 Timeout <u> 0 </u> <u> 8 </u></p> | <p>*03 Zone Types for Zones 9 to 16</p> <p><u> ? </u> <u> ? </u> Zone 9 <u> ? </u> <u> ? </u> Zone 10 <u> ? </u> <u> ? </u> Zone 11 <u> ? </u> <u> ? </u> Zone 12 <u> ? </u> <u> ? </u> Zone 13 <u> ? </u> <u> ? </u> Zone 14 <u> ? </u> <u> ? </u> Zone 15 <u> ? </u> <u> ? </u> Zone 16</p> <p>*05 Zone Types for 25 to</p> <p><u> ? </u> <u> ? </u> Zone 25 <u> ? </u> <u> ? </u> Zone 26 <u> ? </u> <u> ? </u> Zone 27 <u> 0 </u> <u> 0 </u> Not Used <u> 0 </u> <u> 0 </u> Zone 97 Polling LP <u> 0 </u> <u> 9 </u> Zone 95 1 & * <u> 0 </u> <u> 8 </u> Zone 96 3 & # <u> 0 </u> <u> 7 </u> Zone 99 * & #</p> | <p>00 = Disabled 01 = Entry/Exit 1 02 = Entry/Exit 2 03 = Instant 04 = Interior 05 = Day Zone 06 = Silent Holdup 07 = Audible Police 08 = 24 Hour Auxiliary 09 = Fire w/o Verification 10 = InteriorDelay 16 = Fire w/Verification 17 = Fire Water Flow 18 = Fire Supervisory 19 = 24 Hour Trouble</p> <p>00 to 15 x15 seconds 00 to 15 x15 seconds 00 to 15 x15 seconds 00 to 15 x15 seconds 00 to 15 x2 minutes</p> <p>0 = No 1 = Arms/Disarms/Silences Alarms 2 = Silences only if Fire Alarm</p> <p>0 = Disable 1 = Enable</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Randomize 10 - 40 minutes 2 = Randomize 6 - 12 Hours</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = No Report if other Reports Sent</p> <p>000 = Disabled 001 to 199 Hours</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> |
| <p>*15 Keyswitch Enable <u> 0 </u></p> <p>*16 Bell 1 Confirmation of Arming Ding <u> 0 </u></p> <p>*17 AC Loss Keypad Sounding <u> 1 </u></p> <p>*18 Bell 1 AC Loss Alarm <u> 0 </u></p> <p>*19 AC Randomize <u> 2 </u></p> <p>*23 Multiple Alarms <u> 1 </u></p> <p>*24 4190WH Tamper disable <u> 0 </u></p> <p>*25 Burglary Trigger for Zone Type 8 <u> 0 </u></p> <p>*26 Intelligent Test Reporting <u> 0 </u></p> <p>*27 Test Report Interval <u> 0 </u> <u> 2 </u> <u> 4 </u></p> <p>*28 Power up in Previous State <u> 1 </u></p> <p>*29 Quick Arm <u> 1 </u></p> | <p>0 = No 1 = Arms/Disarms/Silences Alarms 2 = Silences only if Fire Alarm</p> <p>0 = Disable 1 = Enable</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Randomize 10 - 40 minutes 2 = Randomize 6 - 12 Hours</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = No Report if other Reports Sent</p> <p>000 = Disabled 001 to 199 Hours</p> <p>0 = No 1 = Yes</p> <p>0 = No 1 = Yes</p> | |

Ademco 5140XM/First Alert FA1500C Program Sheet

| | | |
|--|--|--|
| *30 Main Dialer TouchTone Dialing | 1 | 0 = No 1 = Yes |
| *31 PABX Access Code | | |
| *32 Primary Account Number | 0 ? 0 ? 0 ? 0 ? (2 digit entries) Hex B = 11, C = 12, D = 13, E = 14, F = 15 | |
| *33 Primary Phone Number (12 digits) End Phone with * | # + 11 = *, # + 12 = #, # + 13 = 2.5 second pause | |
| *34 Secondary Phone Number | | |
| *35 Download Phone Number | 1 8 0 0 6 8 2 1 6 9 0 | |
| *36 CSID Number | 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 (15's Default CSID to Factory) | |
| *37 Download Commands Enable | 1 Dialer Shutdown 1 System Shutdown 0 Not Used 1 Remote Bypass 1 Remote Disarm 1 Remote Arm 1 Upload Programming 1 Download Programming | 0 = No 1 = Yes |
| *38 Inhibit Bypass of One Zone | 0 0 | 00 = All zones bypassable 01 to 64 = Zone 01 to 64 |
| *39 Open/Close Report for Installer | 0 | 0 = No 1 = Yes |
| *40 Open/Close Report for Keyswitch | 0 | 0 = No 1 = Yes |
| *41 Normally Closed Zones 3 to 8 | 0 | 0 = EOL Resistors 1 = Normally Closed |
| *42 Dial Tone Pause | 0 | 0 = 5 seconds 1 = 11 seconds 2 = 30 seconds |
| *43 Dial Tone Detection | 0 | 0 = Pause then Dial 1 = Wait for True Dial Tone |
| *44 Ring Detection Count | 1 5 | 15 = Answering Machine |
| *45 Primary Format | 1 | 0 = Ademco Lo 1 = Contact ID 2 = Ademco High Speed 3 = Ademco Express |
| *46 Low Speed Format (Primary) | 0 | 0 = Ademco Low Speed 1 = Sescoa/Radionics |
| *47 Secondary Format | 1 | 0 = Ademco Lo 1 = Contact ID 2 = Ademco High Speed 3 = Ademco Express |
| *48 Low Speed Format (Secondary) | 0 | 0 = Ademco Low Speed 1 = Sescoa/Radionics |
| *49 Checksum Verify | 0 | 0 = No 1 = Yes |
| *50 Sescoa Radionics Select | 0 | 0 = Radionics 1 = Sescoa |
| *51 Dual Reporting | 0 | 0 = No 1 = Yes |

Ademco 5140XM/First Alert FA1500C Program Sheet

*52 Standard/Expanded Report
for Primary

Alarm/Fire Supv
 Restore
 Bypass
 Trouble
 Open/Close
 Low Bat/Walk Test

0 = Standard
 1 = Expanded

*53 Standard/Expanded Report
for Secondary

Alarm/Fire Supv
 Restore
 Bypass
 Trouble
 Open/Close
 Low Bat/Walk Test

0 = Standard
 1 = Expanded

*54 Report Codes for Zones 1 to 8

Zone 1
 Zone 2
 Zone 3
 Zone 4
 Zone 5
 Zone 6
 Zone 7
 Zone 8

*55 Report ID for Zones 1 to 8

Zone 1
 Zone 2
 Zone 3
 Zone 4
 Zone 5
 Zone 6
 Zone 7
 Zone 8

*56 Report Codes for Zones 9 to 16

Zone 9
 Zone 10
 Zone 11
 Zone 12
 Zone 13
 Zone 14
 Zone 15
 Zone 16

*57 Report ID for Zones 9 to 16

Zone 9
 Zone 10
 Zone 11
 Zone 12
 Zone 13
 Zone 14
 Zone 15
 Zone 16

*58 Misc Alarms/Restorals for Zones 1 to 16

Alarm/Supervision Restore
 Trouble
 Trouble Restore
 Bypass
 Bypass Restore

*59 Report Codes for Zones 17 to 24

Zone 17
 Zone 18
 Zone 19
 Zone 20
 Zone 21
 Zone 22
 Zone 23
 Zone 24

*60 Report ID for Zones 17 to 24

Zone 17
 Zone 18
 Zone 19
 Zone 20
 Zone 21
 Zone 22
 Zone 23
 Zone 24

*61 Report Codes for Zones 25 to 32

Zone 25
 Zone 26
 Zone 27
 Zone 28
 Zone 29
 Zone 30
 Zone 31
 Zone 32

*62 Report ID for Zones 25 to 32

Zone 25
 Zone 26
 Zone 27
 Zone 28
 Zone 29
 Zone 30
 Zone 31
 Zone 32

*63 Misc Alarms/Restorals for Zones 17 to 32

Alarm/Supervision Restore
 Trouble
 Trouble Restore
 Bypass
 Bypass Restore

Ademco 5140XM/First Alert FA1500C Program Sheet

***64 Report Codes for Zones 33 to 40**

0 1 Zone 33
 0 1 Zone 34
 0 1 Zone 35
 0 1 Zone 36
 0 1 Zone 37
 0 1 Zone 38
 0 1 Zone 39
 0 1 Zone 40

***65 Report ID for Zones 33 to 40**

0 1 Zone 33
 0 1 Zone 34
 0 1 Zone 35
 0 1 Zone 36
 0 1 Zone 37
 0 1 Zone 38
 0 1 Zone 39
 0 1 Zone 40

***66 Report Codes for Zones 41 to 48**

0 1 Zone 41
 0 1 Zone 42
 0 1 Zone 43
 0 1 Zone 44
 0 1 Zone 45
 0 1 Zone 46
 0 1 Zone 47
 0 1 Zone 48

***67 Report ID for Zones 41 to 48**

0 1 Zone 41
 0 1 Zone 42
 0 1 Zone 43
 0 1 Zone 44
 0 1 Zone 45
 0 1 Zone 46
 0 1 Zone 47
 0 1 Zone 48

***68 Misc Alarms/Restorals for Zones 41 to 48**

0 1 Alarm/Supervision Restore
 0 1 Trouble
 0 1 Trouble Restore
 0 0 Bypass
 0 0 Bypass Restore

***70 Report ID for Zones 49 to 56**

***69 Report Codes for Zones 49 to 56**

0 1 Zone 49
 0 1 Zone 50
 0 1 Zone 51
 0 1 Zone 52
 0 1 Zone 53
 0 1 Zone 54
 0 1 Zone 55
 0 1 Zone 56

0 1 Zone 49
 0 1 Zone 50
 0 1 Zone 51
 0 1 Zone 52
 0 1 Zone 53
 0 1 Zone 54
 0 1 Zone 55
 0 1 Zone 56

***71 Report Codes for Zones 57 to 64**

0 1 Zone 57
 0 1 Zone 58
 0 1 Zone 59
 0 1 Zone 60
 0 1 Zone 61
 0 1 Zone 62
 0 1 Zone 63
 0 1 Zone 64

***72 Report ID for Zones 57 to 64**

0 1 Zone 57
 0 1 Zone 58
 0 1 Zone 59
 0 1 Zone 60
 0 1 Zone 61
 0 1 Zone 62
 0 1 Zone 63
 0 1 Zone 64

***73 Misc Alarms/Restorals for Zones 49 to 64**

0 1 Alarm/Supervision Restore
 0 1 Trouble
 0 1 Trouble Restore
 0 0 Bypass
 0 0 Bypass Restore

***76 Report Codes for Zones 70 to 99**

0 0 Not Used
 0 0 Not Used
 0 0 Not Used
 0 1 Duress
 0 1 Zone 97 (Polling Loop Short)
 0 1 Zone 95 (1 & *)
 0 1 Zone 96 (3 & #)
 0 1 Zone 99 (* & #)

***77 Report ID for Zones 70 to 99**

0 0 Not Used
 0 0 Not Used
 0 0 Not Used
 0 1 Duress
 0 1 Zone 97 (Polling Loop Short)
 0 1 Zone 95 (1 & *)
 0 1 Zone 96 (3 & #)
 0 1 Zone 99 (* & #)

***78 Misc Alarms/Restorals for Zones 70 to 99**

0 1 Alarm/Supervision Restore
 0 1 Trouble
 0 1 Trouble Restore
 0 0 Bypass
 0 0 Bypass Restore

Ademco 5140XM/First Alert FA1500C Program Sheet

***79 Zone Type Restore Enable Zone Types 1 to 8**

- 0 Zone Type 1 (Entry/Exit 1)
- 0 Zone Type 2 (Entry Exit 2)
- 0 Zone Type 3 (Perimeter)
- 0 Zone Type 4 (Interior Follower)
- 0 Zone Type 5 (Day/Night)
- 0 Zone Type 6 (24 Hour Silent)
- 0 Zone Type 7 (24 Hour Audible)
- 0 Zone Type 8 (24 Hour Auxiliary)

0 = No Restoral Report
1 = Restoral Report

***80 Zone Type Restore Enable Zone Types 9 to 10**

- 1 Zone Type 9 (Fire without Verification)
- 0 Zone Type 10 (Interior Delay)

0 = No Restoral Report
1 = Restoral Report

***81 Misc Non Alarm Codes 1st digit**

- 0 0 Close
- 0 0 Open
- 1 1 Low Battery
- 0 0 Low Battery Restore
- 1 1 AC Loss
- 1 1 AC Restore
- 1 1 Communicator Test
- 0 0 Power Up
- 1 1 Cancel
- 0 0 Program Tamper

***82 Misc Non Alarm Codes 2nd digit**

- 0 0 Open
- 0 0 Close
- 0 0 Low Battery
- 0 0 Low Battery Restore
- 0 0 AC Loss
- 0 0 AC Restore
- 0 0 Communicator Test
- 0 0 Power Up
- 0 0 Cancel
- 0 0 Program Tamper

***83 First Test Report Time**

 0 0 | 0 2 | 0 0
Day Hour Minutes

***84 Swinger Shutdown**

 0 3

00 = Disabled
01 to 15 = 01 to 15 Alarms

***87 Entry Warning**

 1

0 = 3 Beeps
1 = Continuous

***88 Burglar Alarm Comm Delay**

 0

0 = No Delay
1 = 16 seconds

***89 Restore Report Timing**

 0

0 = Instant
1 = At Bell Timeout
2 = At Disarm

***90 Secondary Account Number**

_____ (2 digit entries)
Hex B = 11, C = 12, D = 13, E = 14, F = 15

To access Upper programming press *94, to return to lower programming press *99
the 1 isn't part of location, to go to a Upper program location press * + 2-digits

1*01 Zone Types for Zones 28 to 32

- ? ? Zone 28
- ? ? Zone 29
- ? ? Zone 30
- ? ? Zone 31
- ? ? Zone 32

1*02 Zone Types for Zones 33 to 40

- ? ? Zone 33
- ? ? Zone 34
- ? ? Zone 35
- ? ? Zone 36
- ? ? Zone 37
- ? ? Zone 38
- ? ? Zone 39
- ? ? Zone 40

- 00 = Disabled
- 01 = Entry/Exit 1
- 02 = Entry/Exit 2
- 03 = Instant
- 04 = Interior
- 05 = Day Zone
- 06 = Silent Holdup
- 07 = Audible Police
- 08 = 24 Hour Auxiliary
- 09 = Fire w/o Verification
- 10 = InteriorDelay
- 16 = Fire w/Verification
- 17 = Fire Water Flow
- 18 = Fire Supervisory
- 19 = 24 Hour Trouble

1*03 Zone Type for Zone 41 to 48

- ? ? Zone 41
- ? ? Zone 42
- ? ? Zone 43
- ? ? Zone 44
- ? ? Zone 45
- ? ? Zone 46
- ? ? Zone 47
- ? ? Zone 48

1*04 Zone Types for Zone 49 to 56

- ? ? Zone 49
- ? ? Zone 50
- ? ? Zone 51
- ? ? Zone 52
- ? ? Zone 53
- ? ? Zone 54
- ? ? Zone 55
- ? ? Zone 56

Ademco 5140XM/First Alert FA1500C Program Sheet

1*05 Zone Type for Zone 57 to 64

? ? Zone 57
 ? ? Zone 58
 ? ? Zone 59
 ? ? Zone 60
 ? ? Zone 61
 ? ? Zone 62
 ? ? Zone 63
 ? ? Zone 64

1*33 Touch Tone with Rotary Backup 1

0 = Disable
1 = Enable

1*34 Comm Split Report Selection 0

0 = No
1 = Alarms to Primary, others Secondary
2 = O/C/Test Secondary, others Primary

1*40 System Non-Alarm Codes 1st Digit

0 0 Armed Stay
 0 0 Time Set/Event Log Reset
 0 0 Event Log 50 & 90% Full
 0 0 Event Log Overflow

1*41 System Non-Alarm Codes 2nd Digit

0 0 Armed Stay
 0 0 Time Set/Event Log Reset
 0 0 Event Log 50 & 90% Full
 0 0 Event Log Overflow

1*43 Perm Keypad Backlight 1

0 = No
1 = Yes

1*45 - Exit Delay Sounder 1

1 = Enable
0 = Disable

1*47 Chime Annunciation on Bell 1 1

0 = Disable
1 = Enable

1*52 Cancel Report Restriction 1

0 = No Restriction
1 = Within Bell Timeout

1*53 Download Callback 1

0 = Callback Required
1 = No Callback

1*70 Event Log Types 1 Alarm

0 = Disable Logging
1 = Enable Logging

1 Check

1 Bypass

1 O/C

1 System

1*71 12/24 Hour Time Stamp Format 0

0 = 12 Hour
1 = 24 Hour (Military)

1*72 Event Log Printer On-line Mode 0

0 = Disable
1 = Enable

1*73 Printer Baud Rate 0

0 = 1200 Baud
1 = 300 Baud

To access Upper programming press *94, to return to lower programming press *99
the 3 isn't part of location, to go to a Upper program location press * + 2-digits

3*10 Response Type Assignment

0 0 Zone 70 Bell 1
 0 0 Zone 71 Bell 2
 0 0 Zone 72 Earth Ground
 0 0 Zone 73 J2/In 1
 0 0 Zone 74 Dialer 1
 0 0 Zone 75 Dialer 2
 0 0 Not Used
 0 0 Not Used

19 = 24 Hour Trouble

3*15 Alarm Bell Sound 0 Bell 1

0 = Pulsed
1 = Steady

0 Bell 2

3*16 Delay for Zone Types 17 & 18 0 0

00 to 15 x2 seconds

(Waterflow & Fire Supervision)

3*17 Alt Function (Tamper) for Zone 6 0 0

0 = Disabled
1 = Enabled

Ademco 5140XM/First Alert FA1500C Program Sheet

3*71 Bell 1 & 2 Aux Relay Activation Zone 9 to 16

Zone 9
 Zone 10
 Zone 11
 Zone 12
 Zone 13
 Zone 14
 Zone 15
 Zone 16

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*72 Bell 1 & 2 Aux Relay Activation Zone 17 to 24

Zone 17
 Zone 18
 Zone 19
 Zone 20
 Zone 21
 Zone 22
 Zone 23
 Zone 24

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*73 Bell 1 & 2 Aux Relay Activation Zone 25 to 32

Zone 25
 Zone 26
 Zone 27
 Zone 28
 Zone 29
 Zone 30
 Zone 31
 Zone 32

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*74 Bell 1 & 2 Aux Relay Activation Zone 33 to 40

Zone 33
 Zone 34
 Zone 35
 Zone 36
 Zone 37
 Zone 38
 Zone 39
 Zone 40

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*75 Bell 1 & 2 Aux Relay Activation Zone 41 to 48

Zone 41
 Zone 42
 Zone 43
 Zone 44
 Zone 45
 Zone 46
 Zone 47
 Zone 48

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*76 Bell 1 & 2 Aux Relay Activation Zone 49 to 56

Zone 49
 Zone 50
 Zone 51
 Zone 52
 Zone 53
 Zone 54
 Zone 55
 Zone 56

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*77 Bell 1 & 2 Aux Relay Activation Zone 57 to 64

Zone 57
 Zone 58
 Zone 59
 Zone 60
 Zone 61
 Zone 62
 Zone 63
 Zone 64

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

Ademco 5140XM/First Alert FA1500C Program Sheet

3*78 Bell 1 & 2 Aux Relay Activation Zone 70 to 72

0 Not Used
 0 Not Used
 0 Not Used
 0 Not Used
 0 Not Used
 1 Zone 70
 1 Zone 71
 1 Zone 72

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*79 Bell 1 & 2 Aux Relay Activation Zone 73 to 75

1 Zone 73
 1 Zone 74
 1 Zone 75
 0 Not Used
 0 Not Used
 0 Not Used
 0 Not Used
 0 Not Used

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*81 Bell 1 & 2 Aux Relay Activation Zone 95 to 99

0 Not Used
 0 Not Used
 0 Not Used
 0 Not Used
 0 Not Used
 1 Zone 95 (1 & *)
 0 Zone 96 (3 & #)
 1 Zone 99 (* & #)

0 = None
1 = Bell 1
2 = Bell 2
3 = Bell 1 & 2
4 = Aux Relay
5 = Bell 1 & Relay
6 = Bell 2 & Relay
7 = Bell 1 & 2 & Relay

3*82 Enable Burg Features 1 (Away, Stay, Max, Test, Instant, Chime Functions)

0 = Disable
1 = Enable

3*85 Enable Fire & System Zone Bypass 1 (For Zone Types 9, 16, 17 & 18 & Zones 70 to 77)

0 = Not Enabled
1 = Only Installer can Bypass
2 = Only Installer & Master
can Bypass

Monitronics Monitoring and Service: 1-800-447-9239

Ademco 5140XMP/First Alert FA-1500C Quick Reference Guide

| | |
|------------------------------|---|
| Arm Away | Enter User Code + AWAY (2) <i>Note:</i> If system shows NOT READY press * to view open zones |
| Arming Stay | Enter User Code + STAY key (3) |
| Disarming / Silencing Alarms | Enter User Code + OFF key (1) if turning off an alarm enter User Code + OFF (1) again to clear alarm display |
| Instant Doors | Enter 4-digit Code + INSTANT key (7) to arm with all Entry/Exit doors instant and motions bypassed (The Exit Delay is still active with this command) |
| Zone Bypassing | User Code + BYPASS (6) + Zone (01, 02, 15 etc) <i>Note:</i> Fire/Smoke Detector Zones cannot be bypassed |
| Additional Codes | <ol style="list-style-type: none"> 1. Enter MASTER CODE + CODE key (8) 2. Enter User (02 to 99) 3. Enter New User Code 4. Enter Authority Level <p style="margin-left: 40px;"> 1 = Master Code 2 = Manager Code 3 = Standard User Code 6 = Duress Code </p> <p>To delete User Code Enter MASTER CODE + CODE key (8) + User (03 to 69) + Master Code again <i>Note:</i> The Master Code can only be changed by a Service Technician or by Downloading</p> |
| Door Chimes | Master Code + CHIME key (9), if activated the display will show CHIME |
| Trouble Display | <p>NO AC = Loss of AC power to the system LOW BAT = Main panel has a low battery, if LOW BAT appears with a zone number that zone has low battery CHECK = There is a problem with a zone (system will show zone number on display) ALARM = An alarm has occurred, enter 4-digit User Code + OFF (1) to remove</p> |
| Panic Buttons | <p>Activate panic by holding down a combination of digits Press * and # for Police Panic Press 1 and * for Fire Panic Press 3 and # for Medical Panic <i>Note:</i> The Fire and Medical Panics may be reversed or disabled on some systems</p> |

Do not pause more than 2 seconds between each keypress or system will ignore above commands